

DIAM 5

DIAM 5, respects the evolution of the wine aromas.

DIMENSIONS AVAILABLE: 38 / 44 / 47 mm
Diameters: 23,5 mm / 24,2 mm
Other dimensions: please contact us

DIAM 5, a technological closure with a patented composition, manufactured from cork and treated by the exclusive DIAMANT process (eradication of 2,4,6-TCA by supercritical CO2 treatment) validated by independent laboratories.

A consistent closure that offers:

- Unequaled organoleptic performances
- A systematically controlled ^[3] production batch for a releasable TCA ^[1] rate per closure < QL ^[2]
- A controlled and consistent permeability : two options ^[4] of permeability, depending on the profile of your wine
- A consistent closure that reduces bottle variation
- Perfect insertion at bottling ^[5]
- Rapid Dimensional recovery (97% in 30 seconds)
- No leakage or capillary rising ^[5]
- No dust risk ^[5]
- Easy opening

A closure that offers the positive aspects of cork:

- An elastic, natural and ecological raw material
- A material that compliments wine
- A favorite with consumers

A unique guarantee to assure your consumer of a positive wine experience while respecting tradition: **Cork tradition without the risk of TCA.**

[1]- Guarantee per cork

[2]- QL : the Quantification Limit of the analytical method by gase chromatography is 0.5ng/L

[3]- Indicative value according to internal testing, available upon request

[4]- P10 (increased permeability) and P1

[5]- In compliance with our bottling and storage conditions

OENEO Bouchage SAS
Espace Tech Ulrich
66400 Céret - France
Tél : +33 (0)4 68 87 20 20
Fax : +33 (0)4 68 87 35 36
info@oeneo-bouchage.fr
www.oeneo-bouchage.com

OENEO Closures USA
902 Enterprise Way, Suite M
Napa, CA 94558, USA
Tél : +1-707-256-2830
Fax : +1-707-256-2831
info@diam-cork.com
www.diam-cork.com





DIAM 5, a technological closure with a patented composition, manufactured from cork and treated by the exclusive DIAMANT process (eradication of 2,4,6-TCA by supercritical CO2 treatment) validated by independent laboratories.

Technical specifications ^[a]

ORGANOLEPTIC CHARACTERISTICS			
Method	Parameters	Specifications	Tolerances
Soak test in 12% hydro-alcoholic solution acidified to pH 3.5 / 25 corks. SPME/GC/MS	releasable 2,4,6-TCA (ng/L) releasable 2,3,4,6-TeCA(ng/L) releasable PCA (ng/L) releasable 2,4,6-TBA(ng/L)	< QL ^[b] < QL ^[b] < QL ^[b] < QL ^[b]	
DIMENSIONAL CHARACTERISTICS			
Method	Parameters	Specifications	Tolerances
Calliper gauge / 32 corks	Length (mm)	L ± 0.4	AQL 1.5 (A1/R2)
	Diameter (mm)	D ± 0.3	AQL 1.5 (A1/R2)
	Chamfer (mm)	1.0 ± 0.5	AQL 2.5 (A1/R3) ^[c]
PHYSICAL CHARACTERISTICS			
Method	Parameters	Specifications	Tolerances
4 jaw corker / 5 corks	dimensional recovery / 30sec. (%) ^[d]	> 97%	AQL 2.5 (A0/R1)
Traction compression machine / 5 corks	elastic recovery (N/cm2) ^[d]	> 2.5	AQL 2.5 (A0/R1)
Calibrated tubes / 6 corks	liquid tightness (%) ^[d]	100% > 1.5 bars	
On CETIE bottle neck / 5 corks	extraction force (daN)	18 < 100% < 35 ^[e]	
By stirring and filtering / 10 corks	dust content (mg/cork)	≤ 0.3	

The above technical specifications are valid for up to 60 months. They comply with FDA standards (CFR21 code) and 2002/72/CE and 94/62/CE European regulations.

[a] The above specifications assume compliance with manufacturer's bottling and storage guidelines.

[b] QUANTIFICATION LIMIT (QL): the quantification limit by SPME/GC/MS is 0.5ng/L for TCA, it is 1ng/L for TeCA and PCA and it is 2ng/L for TBA. This is an indicative value based on internal methodology, available upon request.

[c] ACCEPTABLE QUALITY LEVEL (AQL): A2/R3 implies that for 32 corks tested: the batch is accepted if a maximum of 2 corks only, show results outside our specifications and the batch is refused if 3 or more corks show results outside our specifications.

[d] The follow up frequency of this parameter is established in order to regularly evaluate our production batches.

[e] Values are established for corks with a diameter between 24 and 24.5mm (length = 44mm) with a silicone-based surface treatment. Washing upon request, please contact us.

* DIAMANT, an OENEO BOUCHAGE / CEA technology (PATENT EP 1 216 123 B1).

OENEO Bouchage SAS
Espace Tech Ulrich
66400 Céret - France
Tél : +33 (0)4 68 87 20 20
Fax : +33 (0)4 68 87 35 36
info@oeneo-bouchage.fr
www.oeneo-bouchage.com

OENEO Closures USA
902 Enterprise Way, Suite M
Napa, CA 94558, USA
Tél : +1-707-256-2830
Fax : +1-707-256-2831
info@diam-cork.com
www.diam-cork.com

